



GEAUGA COUNTY BOARD OF COMMISSIONERS

Walter M. Claypool

Timothy C. Lennon

Ralph Spidalieri

DEPARTMENT OF WATER RESOURCES • Gerard Morgan, P.E., J.D., Director
470 Center Street • Building 3 • Chardon, Ohio 44024-1068

HOW TO CHLORINATE A WATER WELL

- * You will need 2 gallons of Clorox bleach and a hose that reaches from an outside spigot to the well before you begin.

BYPASS THE WATER SOFTENER AND REMOVE ANY CARTRIDGE FILTERS PRIOR TO CHLORINATING

1. Remove the well cap or the vent pipe or plug if the well is equipped with a sanitary seal.
2. Pour one gallon of bleach directly into the well.
3. Connect a hose to a house spigot and run water directly into the well until a chlorine odor is present. Continue running water from the hose into the well while rinsing down the casing for an additional 5-10 minutes.
4. Shut off the water supply to the hose and proceed to systematically open each water fixture inside the home until a chlorine odor is present. Include both hot and cold water taps. Also include the dishwasher, washing machine, showers, laundry tubs, etc. It is very important to get chlorinated water to ALL parts of the distribution system of the home.
5. Close all valves and pour another gallon directly into the well. Recap the well or replace the vent pipe or plug. Leave all valves closed for a period of 12 hours or longer. Toilets may be flushed if necessary.
6. The next day or after your period of shut down, open the hose spigot and discharge water to the ground or drainage ditch until the chlorine odor lessens. Open every household fixture together or one at a time and let the water run. Be sure your next load of laundry is all whites! The well should now be properly disinfected, however, depending on the severity of the contamination; this procedure may need to be repeated.

Have your water analyzed again until you maintain two negatives. It is recommended that you wait at least 48 hours after chlorinating before a sample is taken.